

NOTE:

A change in all amplifiers coded "H" and above removes the positive voltage from the stators of the swell assembly. This can be incorporated in earlier amplifiers by following the steps below. The end result will place a blocking condenser (.02 mfd, 600v) between pin 1 of the 12AX7 and the swell stators. This change will insure continued noise free operation of earlier amplifiers.

(See Figure 16 of Service Manual)

- Step #1 - Move lower lead of C17 from lug B to lug A. Remove jumper.
- Step #2 - Move lower leads of R33, R35, C16 and Green lead from lug C to lug B.
- Step #3 - Move lower lead of R32, C15 and Blue lead (C15) from lug D to lug C.
- Step #4 - Add C9 from lug C to D.

