


SpeakEasy Vintage Music, Inc.




C100 and C101 are 68pF 500v

"L" is the LOUD stator plate of the expression cap it is wired to the junction of C16, C18, and R30

"S" is the SOFT stator plate of the expression cap it is wired to the junction of C20, R32, R33, and R34

"G" is the rotor of the expression cap it is wired to the junction of C17, C22, R35, and Pin 7 of Y4



MODIFIED ERNIE BALL 6166 PEDAL
 OUTPUT AND TUNER JACKS REMOVED
 INPUT "RING" TERMINAL WIRED TO
 POT WIPER ON PCB

SPEAKEASY VINTAGE MUSIC

AO-28 Expression Control

T. Thompson

Rev 2.0
 4/4/2007

Do not curse the
 darkness,
 light a candle