



NOTE: IF FOR U5, U8, U12 OR U16 A 2764 EPROM IS PLACED INSTEAD OF A 27128 EPROM, THE 1/2 4013 (U6 AND U13) USED FOR SWITCHING THE UPPER BK ROM AND THE LOWER BK ROM, IS NOT NECESSARY.

VOICE CARD		REV.
DESIGN	LAB	18-04-94
DRAWN	VERSCHOOR	
SWEELINCK II		PAGE 12